


F.O.G. BATTERY PARTS LIST



HF01XXXFOG CONTAINER

Stainless steel construction. Includes container access cover assembly (HF82), two 8" diameter wheels (HF035), two cotter pins (HF035A) and breather vent assembly (HF83) and 1/2 quick disconnect nipple (HF611).
 HF01065FOG – 18" x 20" x 10.5"
 HF01130FOG – 18" x 20" x 17.5"

HF035 8" DIAMETER WHEEL (Not Shown)

HF035A COTTER PIN 2" FOR WHEEL RETENTION (Not Shown)

HF05048 DISCHARGE SUCTION HOSE

1/2" diameter., 48" length, wire reinforced hose with 2 hose nipples and ferrules.

HF06048FOG DISCHARGE SUCTION HOSE ASSEMBLY

Includes Discharge/Suction Hose (HF05048) and 1/2" quick disconnect coupler (HF610)

HF11FOG FOG DISCHARGE NOZZLE

Nickel plated pipe with black handle and 1/2" coupling (HF41A).

HF1106FOG FOG NOZZLE HOSE ASSEMBLY

Includes nozzle (HF11FOG) and Discharge/Suction hose and assembly (HG06048FOG)

HF12 DISCHARGE NOZZLE HANDLE

Black, phenolic, to fit discharge nozzle.

HF13FOG FOG POWER UNIT

Stainless Steel Construction "Mailbox" shape. Includes housing (HF14FOG), base (HF22FOG), rechargeable battery (HF53), motor (HF21FOG), coupling (HF52D), pump (HF580), pipe nipple (HF68), quick disconnect nipple (HF611), quick disconnect coupler (HF610) and straight nipple (HF85).

HF14FOG FOG POWER UNIT HOUSING

Stainless steel "Mailbox" cover. Includes housing handle, toggle switch, switch guard, lead wire and grommet.

HF155 POWER UNIT HOUSING HANDLE

Located on top of Power Unit Housing (5" center to center).

HF16MMEFOG FOG POWER UNIT SWITCH

Reversible two way toggle switch.

HF16G POWER UNIT SWITCH GUARD

Located over switch

HF17 GROMMET

Black rubber piece located on top of housing.

HF18CHRG BATTERY CHARGER

Used to charge battery.

HF18FOG FOG LEAD WIRE

Connects battery charger to battery

HF18FA FUSE ASSEMBLY

Includes Fuse holder & fuse.

HF18FH FUSE HOLDER

Holds 15 AMP fuse. Located on the underside of the Power Unit Base.

HF18FUSE 15 AMP FUSE

HF21FOGB FOG MOTOR; BATTERY OPERATED

12VDC, reversible.

HF22FOG POWER UNIT BASE

Stainless steel, rectangular shape. Includes base feet (HF23), battery clamp (HF53B) and fuse assembly (HF18FA).

HF23 BASE FEET

Located on bottom of power unit base.

HF47 BELL FILTER ASSEMBLY

Stainless steel construction. Consists of bell filter screen (HF47B) and 1/2" x 5" stem (HF68).

HF47B BELL FILTER SCREEN

1 1/2" OD mesh screen. Screws onto 5" nipple (HF68).

HF48 CHECK VALVE

HF52D DOUBLE LOOP COUPLING

Used to connect shaft of motor with shaft of pump.

HF53 BATTERY

Rechargeable, 12VDC, maintenance free, self-contained. Provides power to motor.

HF53B BATTERY CLAMP

Used to secure battery to power unit base.

HF580B PUMP

Open Coupling Pump

HF610D 1/2" QUICK DISCONNECT COUPLER

1/2" coupler, nickel plated, with white handle used to attach power unit to container and hose to power unit.

HF611D 1/2" QUICK DISCONNECT NIPPLE

1/2" nipple nickel plated, used to attach power unit to hose assembly and container to power unit.

HF68 5" PIPE NIPPLE

1/2" diameter pipe. Threads into pump from top of housing. Threads into quick disconnect nipple (HF611D). Also threads into bell filter screen (HF47B) and end of discharge nozzle (HF11FOG).

HF82 ACCESS COVER ASSEMBLY

6" diameter. Cover consists of access cover (HF82A), float (HF82C), screws (HF82D), gasket (HF82F) and level indicator rod (HF82G).

HF82A ACCESS COVER

6" diameter. Stainless steel material threads into container.

HF82B LEVEL INDICATOR ROD

Stainless Steel. Raised from cover it indicates a full container.

HF82C FLOAT - Stainless Steel

HF83 BREATHER ASSEMBLY

Includes breather vent (HF84) and check valve (HF48)

HF84 BREATHER VENT

Stainless steel mesh construction. Allows airflow in and out of container.

HF85 1/2" x 1 1/2" STRAIGHT NIPPLE

HF91 "T" HANDLE

Attaches to rear of the container, used to tilt and move F.O.G. unit. Has holder for battery charger and nozzle bell filter assembly. HF9165 for – HFFOG65 model
 HF91130 for – HFFOG130 model

HF92 HANDLE GRIP FOR "T" HANDLE

HF93 RETAINING PIN

Used to hold "T" handle in place on the container.

HF97 DRAIN PLUG FOR FOG CONTAINER (Not Shown)

HF98 HOLDER FOR NOZZLE

HF99 HOLDER FOR BATTERY CHARGER